



**BA 090T, BA 090G, BA 090S,  
BA 290 & BA 290G.  
Bumperettes.  
Fitting Instructions.**

Tools Required:  
Spanners/sockets.

The bumperettes are easy to fit. They use the existing bolts that are on the chassis. (The ones for the grab handles). Simply remove the bolts as shown in the picture below, fit the bumperette and replace the bolts.

