



## **BA 2C2, BA 2C, BA 5 & BA 5/2 Fitting Instructions.**

To fit S3 & DEF

Kit List

1 x Bar

8 x 1"x7/16 UNF set bolts

8 x 7/16 Nyloc nuts

8 x 7/16 Washers

For Series 3

- 1 Offer the bull bar up to the bumper on the front of vehicle.
- 2 Mark the 8 fixing holes through the base of the bar.
- 3 Drill 8 holes to take the 7/16 UNF bolts.
- 4 Bolt the bar to the bumper.

For Defender

- 1 Remove bumper mounting bolts and offer the bull bar to the bumper.
- 2 Replace bumper mounting bolt passing through the holes in the base of the bar.
- 3 Mark and drill the 4 holes through the front of the bumper and secure the bar with the bolts provided.