



BA 088 Freelander Rock Sliders Fitting Instructions.

Kit List:

- 2 x Rock Sliders.
- 8 x Brackets.
- 4 x Spacers.
- 10 x Bolts (13mm Socket).

Instructions:

- 1 Arrange the kit so the correct brackets are used the correct position. See photograph.



- 2 Remove the plastic trim from around the jacking points on the vehicle. There are new jacking points on the Rock Sliders.
- 3 Offer up the Rock Slider to the vehicle in order to identify the mounting points, The brackets now need to be inserted into the vehicle's chassis. This is done by feeding the brackets through existing holes in the chassis and then positioning them in the correct place. Make sure the smooth face of the bracket faces down and the nut faces up. See Photograph.



- 4 One of the rear brackets needs to be mounted inside the vehicle. When the slider is offered up to the vehicle it can be seen that a grommet needs to be removed (See Photograph). To do this the carpet needs to be lifted and the grommet pushed from the outside, into the vehicle. Place the bracket inside,



(and spacers on the outside if required) and refit the carpet.

- 5 The Rock Sliders can now be fitted to the brackets using the bolts provided. Although tricky to start the bolts, once in and tightened they provide a strong and sturdy support for the sliders.