

BA 091 Defender Dog Guard Fitting Instructions.

Fit the upper brackets to the lip inside where the roof meets the side panels as shown in the photographs. To do this it may be necessary to remove some of the interior trim.



View through Alpine Window

Interior View Upper Bracket.

Tilt the rear seats forward (for 110) and locate the bolts that secure the rear side facing seats. Remove the bolts and slide the lower dog guard brackets under the seat mounting points. Replace the bolts and tighten.



Lower Bracket

Now hook in the dog guard into the top brackets and secure in place to the bottom brackets using the hand bolts provided.