



BA 095 / BA 096 RR Bull Bar Fitting Instructions

Kit Contents.

- 1 Bull Bar
- 2 Brackets
- 4 10mm bolts
- 4 10mm nyloc nuts
- 8 10mm flat washers

- 1 Cut two slots in the front spoiler as shown.
- 2 Attach the brackets to the chassis using the bumper mounting bolts.
- 3 Pass the bull bar through the slots in the spoiler and bolt to the bracket.

