

BA 104 Discovery Lamp Guards. Fitting Instructions.



1 Open the bonnet and push the plastic inserts into the square holes in the front slam panel.



2 Slide the bottom bracket onto the bumper and into position (do not tighten onto the bumper yet). It may be necessary to slacken the bumper bolts to do this.



3 Attach the lamp guard to the plastic inserts in the slam panel with the screws provided.



4 Now align the bottom bracket with the lamp guard and tighten the screw. Finally tighten the screw through the underneath of the bottom bracket and check the lamp guards are secure before driving.