

BA 2158,BA 2159 & BA 2162 Twin Shock Mount Rear

- 1 Removal of the road wheels will be necessary for fitment of the twin shock mounts.
- 2 Weld the bottom bracket to the axle casing opposite the existing ones, as shown in the photographs below.



- 3 Mount the top shock mounting bracket to the chassis and fit the damper as shown below.



- 4 Re fit road wheels and check all fixings are secure before driving.