



## **BFA 3002, BFA 3003, BFA 3004 Freelander Lamp Guards. Fitting Instructions.**

Kit consists of:

BFA 3002 2 Front lamp guards.  
BFA 3003 2 Rear lower lamp guards (bumper).  
BFA 3004 2 Rear upper lamp guards  
(supplied separately).

Fitting of the guards is easy. The rear guards simply use the light lens fitting screws.



The front guards insert underneath the headlamps and screw into the plastic, on the rear of the headlamps.

